| u | Œ | v. |
|---|---|----|

# **USER MANUAL**

Barcode Scanner No.14952

# CERTIFICATE Inspector Date of manufacture:



## DELI GROUP CO., LTD.

301 Xuxiake Ave. Ninghai County
Ningbo 315600 China Made in China
info@phdeli.com



Dear customers, thank you for your purchase of our products. We are committed to providing our customers with high quality products. To ensure best performance,

## How to use a barcode scanner correctly


please read this manual carefully before use!

- 1. To read a barcode successfully, please move it closer to the scan window if the barcode is small; otherwise move it slightly further away if the barcode is large.
- In case of high specular reflection (e.g. laminated barcode stickers), please tilt the scanner in an appropriate angle to achieve a successful decode.
- 3. To scan a barcode, aim correctly and ensure the scan line crosses every bar and space of the symbol, otherwise, there might be an error



Scan small barcodesfroma short distance.

Tilt to read laminated barcodes




Scan large barcodes from a long distance

## Overview of scanner parts



## Removing the interface cable



# Remove the interface cable as follow

1 Find the cable removal hale on the hattam of the barcode scanner(as shown in the figure above).

2. Insert a paper clip-like fine needle into the hole, and press the paper clip hard. Meanwhile, carefully slide out the cable from the barcode scanner port.

02

01

## Packing list

03

Troubleshooting

Problem

anned data

Incorrect input method

ther scanne

Simple maintenance methods

a mild detergent-water solution

1. Stains and dusts on the scanning window can some-

good-quality tissue to gently wipe the scanning window and then blow any excess dust from the window using a dust blower. Use of poor-quality tissue for a long period

of time will damage the surface smoothness and affect reading accuracy. 2 The shell of the scanner may be cleaned with a soft cloth. If needed, clean the exterior using a soft cloth with

times affect the scanner's performance. Please

Barcode Scanner×1, USB Cable×1, User Manual×1,

### Technical parameters

| Operating voltage     | DC 5V±0.25V  |
|-----------------------|--|
| Operating current     | 185mA (typical value)  |
| Peak current          | 210mA  |
| Standby current       | ≤50mA (Manual Reading Mode)  |
| Light source          | White Light LED; Red Light LED   |
| Barcade types         | ID&2D code   |
| Resolution            | 1D code≥4.7mil 2D code≥10mil   |
| Applicable barcodes   | ID code: AIM-128, Code II, Code 39, Code 93, Code 93, Code 93, Code 94, Code 95, Code 95, Code 95, Code 95, Code 95, Code 95, Code 96, Cod |
| Operating temperature | 0 C~+45 C  |
| Storage temperature   | -20 C~+60 C  |
| Operating humidity    | 5%~90% (No condensated water)  |
| Indication            | Buzzer/Indicator Light   |
| Interface type        | USB  |
| Scanning mode         | Manual/continuous  |
| Anti-shock capability | Pass the 1.2m free fall test   |
|                       |  |





## Decoding sound setting





# Set scanning mode









To add a carriage return



## Set global configuration code



The table of toxic and hazardous substances/elements and their content

×

\_ 0 ]

damage to people and property. Environment-Friendly Use Period:

molded parts

Products.

content.

Special disclaimer

Hg Cd Cr(VI) PBB PBDE 0 0 0 0 0

0 0 0

0 0 0

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T 11363-2006 « Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products> X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T

11363-2006 «Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information

Products ». Due to limitations of science and technology development, these toxic or hazardous substances cannot be replaced or reduced for now. Under normal use

conditions, no leakage or abrupt change will occur within 10 years, nor will it cause pollution to the environment or

This mark refers to the environment-friendly use period of electronic and electrical products sold in accordance with the Regulation of the People's Republic of China on

Limit on Use of Hazardous Substances in Electric and Electronic Products and General Guidelines of Environ-ment-friendly Use Period of Electronic Information

While information of this manual has been carefully

checked for accuracy, no guarantee is given for the completeness and correctness of the contents. Such errors and omissions will be corrected in the new edition of user manual without further notice. The intellectual

property of this manual belongs to our company and no

organization or individual is allowed to change the

0 0

0



# Common suffix setting





# Maintenance

Solution

Ensure the host is plugged in and curned on. When using the USB coble, plug it into the computer's motherboard USB ports, no extended USB ports or USB extension cord should be used.

Scan the setup symbol to enable this type of barcode

n at the barcode before scan

Change the input method to Standard English.

Restore the scanner to factory defaults, or contact the manufacturer service center.

Select the keyboard layout of your country.

- 1. For product failures occur under normal operating circumstances, free of charge repair service shall be provided by our company within one year commencing from date of purchase.
- 2. The period of warranty shall start from the date of purchase and invoice date.
- 3. Customers are required to present the warranty card and the invoice upon request for repairing service.
- Please keep this warranty card in proper condition for free warranty service. There is no replacement if lost. The purchase date filled must be consistent with what is indicated in the invoice, otherwise it will be invalid.

  5. Any alteration to this warranty card renders it invalid
- Our Repair Service Center will be glad to provide services to customers for out-of-warranty products.

# Under any of the following circumstances, no free of charge repair service shall be provided:

- The warranty period has expired.
   The user cannot present the invoice or dated proof of
- 3. The user requires a replacement of the product with the excuse that the product appearance looks old
- naturally due to use.

  4. Machine failure is caused by use in violation of
- Machine failure is caused by falling or collision.
- 6. Machine failure is caused by self-assembly, self-disassembly and self-repair.
- 7. Commercial samples and goods sold at reduced prices, as well as products that have undergone performance

★ Note: The information in this document is subject to change without notice.